

Electromagnetic Relationships and Formulas

Impedance (for an inductor) $|Z| = R + jX_L$ $|Z| = \sqrt{R^2 + X^2}$

Core Constant $C_1 = \Sigma \frac{l_e}{A_e}$; for a toroid (Ht in cm) $C_1 = \frac{2\pi}{Ht \times \ln(OD/ID)}$

Inductance L $\frac{N\phi}{I} = \frac{\# \text{ Flux linkages}}{\text{current that produces flux}}$

Attenuation (dB) = $20 \text{ Log}_{10} \left[\frac{Z_s + Z_L + Z_{SD}}{Z_s + Z_L} \right]$

For Toroids (SI Units)

Magnetic Field Intensity (H)
(Amperes/meter)

$$H = \frac{NI}{2\pi r}$$

Magnetic Flux Density (B)
(Webers/meter²)

$$B = \frac{\mu NI}{2\pi r}$$

Inductance (L)
(Henries)

$$L = \frac{4\pi\mu_e N^2}{C_1} \times 10^{-9}$$

Quality Factor (Q)

$$Q = \frac{\omega L_s}{R_s} = \frac{R_p}{\omega L_p}$$

Effective Permeability (μ_e).....

$$\mu_e = \frac{l_e}{l_e / \mu_i + l_g} \text{ where } l_g \ll l_e$$

Equation Variables

- | | |
|--|---|
| μ = $\mu_r \mu_0$ | I = current in amperes |
| μ_r = relative permeability of the core | ID = inside diameter of core |
| μ_0 = permeability of free space = $4\pi \times 10^{-7}$ Henries/meter | OD = outside diameter of core |
| μ_e = effective permeability of the core | N = number of turns |
| ω = $2\pi fL$ | R_s = series resistance |
| l_e = effective path length | jX_L = imaginary component of inductive reactance |
| l_g = length of gap | X_L = $2\pi fL$ |
| r = mean core radius | Z_s = source impedance |
| f = frequency | Z_L = load impedance |
| A_e = effective cross-sectional area | Z_{SD} = shielding device impedance |
| Ht = height of core | |