

The Agribar Operator's Manual

By: R.K. Bansal

Published by: International Crops Research Institute for the Semi-Arid

Tropics

Patancheru, A.P. 502 324

India

Available from: International Crops Research Institute for the Semi-Arid

Tropics

Patancheru, A.P. 502 324

India

Reproduced with permission.

Reproduction of this microfiche document in any form is subject to the same restrictions as those of the original document.

FIELD OPERATIONS




TROPICS CROPS RESEARCH INSTITUTE FOR THE SEMI-ARID NTERNATIONAL

The Agribar Operator's Manual

Field Operations

R.K. Bansai



International Crops Research Institute for the Semi-Arid Tropics

Patancheru, Andhra Pradesh 502 324, India, 1989



The Agribar Operator's Manual: Fieid Operations

Compiled by R.K. Bansal

The International Crops Research Institute for the Semi-Arid Tropics is a nonprofit scientific educational institute receiving support from donors

through the Consultative Group on International Agricultural Research. Donors to ICRISAT include governments and agencies of Australia, Belgium, Canada, Federal Republic of Germany, Finland, France, India, Italy, Japan, Mexico, Netherlands, Nigeria, Norway, People's Republic of China,

Sweden, Switzerland, United Kingdom, United States of America, and the

following international and private organizations: Asian Development

Bank, Deutsche Gesellschaft für Technische Zusammenarbeit (GTZ), Global 2000 Inc., International Development Research Centre, International Fertilizer Development Center, International Fund for Agricultural Devel-

opment, The European Economic Community, The Ford Foundation, The Leverhulme Trust, The Opec Fund for International Development, The

Rockefeller Foundation, The World Bank, United Nations Development Programme, and the University of Hohenheim. Information and conclu-

sions in this publication do not necessarily reflect the position of the aforementioned governments, agencies, and international and private organizations.

Credits:

- Shirley Parfitt - J.B. Wills Conceptualization and design Editing

- S.M. Sinha Art direction and production coordination

N.K. Awadhwal

and Barry D. Hall H.S. Duggal, - A.B. Chitnis, **Photography**

- M.M. Babu Basin engineering drawings

- A.A. Majid Illustrations, final drawings, and art work

 Composing Unit staff Typese: 'ng Printing

Associated research and assistance in preparing the manual

Staff of the Engineering

- V.M. Mayande and

Printshop staff

Management Program,


Group, Resource

Financial assistance in the publication of this manual from the New Zealand

High Commission, New Delhi, India, is gratefully acknowledged.

ISBN 92-9066-126-7


Citation: Bansal, R.K. 1989. The Agribar operator's manual: field operations. Patancheru, A.P. 502 324, India: International Crops Research Institute for the Semi-Arid Tropics.



Contents


2	AGRIBAR COMPONENTS	20 E	BROADBEDS
4	Attachments for cultivation	20	The broadbed-and-furrow system
5	Attachments for sowing	20	Marking the slope of the land
		21	Shaping
6	AGRIBAR ASSEMBLY	21	Making broadbeds for the first time
-		22	Adjusting the depth and pitch
0	FLAT LAND	22	1st pass
		23	2nd pass
0	Plowing	23	3rd pass
Õ	Preparation for plowing		•
1	Hitching the bullocks	25	Plowing
1	Depth adjustment	26	1st pass: opening the center of the broadbed
2	Pitch adjustment	28	2nd pass: plowing at 70-cm spacing
4	Width of cut	30	3rd pass: plowing at 110-cm spacing
4	Plowing	32	4th pass: tiliage in the furrows
6	Cultivation	34	Cultivation
6	Cultivation with rigid tines	34	Cultivation with rigid tines
8	Cultivation with a blade harrow	36	Cultivation with a blade harrow
		38	Shaping with a chain
		40	Sowing and fertilizer application
		42	Preparation for sowing broadbeds at 30-cm spacing
		45	Sowing broadbeds at 30-cm spacing
		46	Sowing an intercrop at 45-cm spacing
		50	Interrow cultivation at 30-cm spacing
		54	Interrow cultivation at 45-cm spacing

AGRIBAR COMPONENTS




Tools for Agribar assembly Spanner 17/19 **Pliers** Spanner 24/26 **Tommybar** Hammer **Recommended spares Bolts** Split pins Nuts L-pins **Flat washers Spring washers**


Attachments for cultivation



These markings show the positions of the attachments




Attachments for sowing



AGRIBAR ASSEMBLY


Fixing the beam to the polbar



Fit the end of the beam between the 2 plates on the toolbar

9

Insert a larg wolt from the left side



Fit a spring washer and nut and tighten firmly








The L-pin should pass all the way through a hole on the beam and the right plate

Secure the L-pin by inserting an R-pin

Adjusting the pitch










Fixing the handle assembly

Fix the handle assembly to the plates







Fixing the seat to the tool tray








Fixing the wheel support assemblies











FLAT LAND: Preparation for plowing

Plowing of flat land with a single moldboard plow











Hitching

Depth adjustment

Hitch the bullocks 80 cm apart







Loosen the eye bolts on either side of the depth adjusters




Slide the depth adjusters:






backwards to reduce the depth of working



forwards to increase the depth of working


Pitch adjustment


Check if the plow standard is vertical












Take the Agribar to the field, lower the toolbar and begin plowing

Lower the toolbar by lifting the handles



Check the depth of working, and the pitch, and make adjustments if necessary



Width of cut

Check the width of cut



To reduce the width of cut and lighten the load on the bullocks, loosen the clamps and move the plow slightly to the right


Firmly tighten the clamps

IFLAT LAND plowing

Operating the plow

1st pass


Plow the 1st pass in a straight line



Before turning, lift the plow fully


nd pass

Position the right wheel in the furrow, and lower the toolbar



3 rd pass

Position the right wheel on the plowed land



Caution


Select the right width and depth of plow to avoid straining the bullocks.


Lift the toolbar fully before turning.

Plow when the soil is in good condition to avoid straining the bullocks.

4 th pass

The toolbar is not level when the right wheel is on the plowed land ...





so level the toolbar by sliding the depth adjusters ...



backwards to reduce the depth



or forwards to increase the depth


FLAT LAND: Cultivation with rigid tines


Position of the wheels

For cultivation, the right wheel can be at end of the toolbar ...




or near the center of the toolbar. This position is preferable because it avoids running the wheels over cultivated soil






Checking the position of the tines



Checking the depth adjustment of the tines




Start cultivating from one end of the field and observe the depth of working


If necessary adjust the depth of working



Slide the depth adjusters backwards to reduce the depth of working...



Silde the depth adjusters forwards to increase the depth of working ...




FLAT LAND: Cultivation with a blade harrow


Fit a steerable toolbar to the main toolbar

Insert locking pins


Fit a 120-cm blade harrow to the center of the steerable toolbar




Fix the blade harrow with 2 clamps





If necessary, adjust the depth of working





depth of working ...







Caution

When turning at the end of a pass, raise the toolbar fully to avoid damage to the attachments.

BROADBEDS


The broadbed-and-furrow system

This system of cultivation is good for deep black soils (Vertisols)

Crops are grown on broad seedbeds separated by furrows 150 cm apart



Marking the slope of the land



The broadbeds should be on a slope of about 0.4-0.8% Mark the key line with pegs (or lime)

If the broadbeds are completely level, there will be no drainage




If the broadbeds slope too much the water will run off, causing erosion



BROADBEDS: Shaping


Making broadbeds for the first time


Fit 2 ridgers on the toolbar directly behind the wheels



Hitch the bullocks 150 cm apart directly ahead of the wheels

Take the Agribar to the field






Adjusting the depth and pitch


Slide the depth adjusters forward to increase the depth of working

Slide the depth adjusters backward to reduce the depth of working



1 st pass


Continue moving parallel to the key line




Lift the toolbar before turning

If necessary, adjust the pitch

If the ridger standard is not vertical ...



align the hole in the beam with another hole on the plate to make the ridger vertical



nd pass


Position 1 wheel and 1 bullock in the previous furrow. Lower the toolbar and start moving



Lift the toolbar before turning

3 rd pass

Position 1 wheel and 1 bullock in the previous furrow. Lower the toolbar and start moving



Lift the toolbar before turning



Caution


in the first pass be careful to follow the key line.

Work at a shallow depth so that the bullocks may walk in a straight line without strain.

Always turn outside the field or in the waterway,

and lift the toolbar fully before turning.

BROADBEDS




BROADBEDS: Plowing

Primary tillage on existing broadbeds is done in 4 passes


st pass
with 1 ridger





nd pass





with 2 plows








th pass

with 2 ridgers






st pass

Opening the center of the broadbed


Fit the ridger in the center of the toolbar




Fit the wheels at the ends of the toolbar

Take the Agribar to the field

Lower the toolbar by lifting the handles ...





Adjusting the depth


Slide the depth adjusters to alter the depth of working







Adjusting the pitch

If the standard is not vertical, move the L-pin to another hole to change the pitch








Complete making furrows in the center of the broadbeds throughout the field


Plowing at 70-cm spacing

Remove the ridger

Fit 2 plows to the toolbar







Adjusting the depth


Slide the depth adjusters to alter the depth of working




Adjusting the pitch

If the standard is not vertical, move the L-pin to another hole to change the pitch







Finish plowing the field

Caution

Make the turns outside the field or in the waterway.


Lift the toolbar fully before turning.


Drive the bullocks carefully so that they walk in the furrows without strain.

Tighten the clamps occasionally while working.

Plowing at 110-cm spacing

Change the position of the plows







Adjusting the depth


Adjusting the pitch


Slide the depth adjusters to alter the depth of working

If the standard is not vertical, move the L-pin to another hole to change the pitch











Finish plowing the field

4th pass

Tillage in the furrows






Fit 1 ridger behind the wheel 75 cm from the center


Position the wheels in the furrows






Adjusting the depth

Slide the depth adjusters to alter the depth of working



Adjusting the pitch

If the standard is not vertical, move the L-pin to another hole to change the pitch




Finish ridging the field




BROADBEDS: Cultivation with rigid tines


Fitting the steerable toolbar and rigid tines



Checking the height of the tines




The rigid tines fitted for cultivation




Adjusting the depth


Slide the depth adjusters to alter the depth of working



Adjusting the pitch

If the standard is not vertical, move the L-pin to another hole to change the pitch






Finish cultivating the field




BROADBEDS: Cultivation with a blade harrow

Fitting the blade harrow and 2 ridgers



The ridgers and blade harrow fitted for cultivation




Check the position of the blade harrow and the ridgers




Adjusting the depth


Adjust the depth by changing the height of the blade



Adjusting the pitch

If the standard is not vertical, move the L-pin to another hole to change the pitch









Caution

Make the turns outside the field or in the waterway.


Lift the toolbar fully before turning.


Drive the bullocks carefully so that they walk in the furrows without strain.

Tighten the clamps occasionally while working.


BROADBEDS: Shaping with a chain

Bed shaping is the last part of seedbed preparation





The chain attached for final bed shaping



Adjusting the depth



Move the hooks to one of the upper holes to decrease soil movement

Move the hooks to lower holes to increase soil movement





Adjusting the depth

Slide the depth adjusters to alter the depth of working:



backwards to decrease depth



forwards to increase depth

Caution

Make the turns outside the field.


Lift the toolbar fully before turning.

Drive the bullocks carefully so that they walk in the furrows without strain.

BROADBEDS: Sowing and fertilizer application

Sowing a sole crop

The Agribar can sow up to 4 rows






The Agribar can sow a sole crop at any row spacing

Sowing an intercrop

The Agribar can sow an intercrop








The Agribar can sow an intercrop at any row spacing

Recommended spacing of

rows










90 cm






Fertilizer application


Fertilizer is placed 3 cm to the side of the seed





Preparation for sowing BROADBEDS at

Fitting the 4 furrow openers










Check that the furrow openers are 30 cm apart


30-cm spacing

Fitting the T-stand




Fitting the tubes

Fit 2,4-hole wooden bowls to a T-stand



Fit the T-stand to the center of the toolbar using a clamp


Fitting the springs



Notice that a spring wire projects from the hole in the furrow openers




Fitting the tubes to the furrow openers



Sowing BROADBEDS at 30-cm spacing




2 persons are needed to drop the seed and fertilizer into the wooden bowls






Check the depth of seed placement in all 4 lines


Adjust the depth by varying the height of the furrow openers or by moving the depth adjusters




BROADBEDS: Sowing an intercrop at 45-cm

Fitting the 3 furrow openers









Check that the furrow openers are 45 cm apart

spacing (cereal and pigeonpea)


Fitting the T-stand and single stand



Fitting the tubes




Fitting the tubes to the furrow openers




Sowing cereal and pigeonpea with fertilizer

3 persons are needed to drop the fertilizer, cereal seed, and pigeonpeas into the bowls




Check the depth of seed in all 3 lines

If necessary, adjust the depth by sliding the depth adjusters ...








Note

The photograph illustrates the choice an operator has in placing the bowls. Here, the cereal seed and fertilizer bowls have been interchanged for operational convenience.

or by changing the height of the furrow openers



Caution


Turn outside the field or in the waterway.

Lift the toolbar fully before turning.

Apply recommended quantities of seed and drop them evenly into the bowls.


Check the openings of the furrow openers often to see that they are not blocked.


BROADBEDS: Interrow cultivation at 30-cm



Fitting the steering handle


Fit the steering handle to the steerable toolbar





spacing


Fitting the ridgers



Fitting the rigid tines




Position of the ridgers and tines



The steerable toolbar

The steering handle moves the steerable toolbar to avoid damaging the crop





Take the Agribar to the field

Lower the toolbar by lifting the handles









or by changing the height of the tines






Fitting the rigid tines



Fit 2 rigid tines on the steerable toolbar



1 person is needed to steer the steerable toolbar

Adjust the depth by sliding the depth adjusters ...



or by changing the height of the tines



Lower the toolbar by lifting the handles





Caution

Make the turns outside the field.

Lift the toolbar fully before turning.

Drive the bullocks carefully and steer the toolbar carefully to avoid damaging the crop when the plants are not in straight rows.